

NOMAFLEX[®]

Cutter

Proprietary cutter for use with
Nomaflex[®] Expansion Joint



The Nomaflex[®] Cutter is an innovative scoring tool, for use with Nomaflex expansion joint, that enables installers to create a void when sealant is required, eliminating the need for a separate void cap system.

PERFORMANCE

The easy-to-use Nomaflex Cutter enables concrete installers to trim Nomaflex expansion joint on the job site to create a 1/2" void for sealant. Nomaflex expansion joint remains flexible and easily fits around curves and radii and the tear strip stays in place until the installer removes it. The Nomaflex Cutter eliminates material costs and labor of an additional void cap system. Nomaflex expansion joint is an inherent bond-breaker, so no additional bond breaker is required.

Additionally, Nomaflex expansion joint is waterproof and can be stored outside. It will not break or flake due to weather elements. Nomaflex lasts longer and is 100% recyclable. Installers have the added benefit of a lower installed cost when using Nomaflex.

HOW TO USE

Installers simply align the Nomaflex expansion joint within the Cutter's channel and pull the Cutter to score a tear strip. Nomaflex is then installed and concrete poured. Once the concrete cures, the tear strip is removed and the sealant is applied. The Cutter is available in the same thicknesses as Nomaflex: 1/2", 3/4" and 1".

Nomaflex Features

- Natural bond breaker
- Ultra lightweight
- Flexible, bends to 12" diameter
- Moisture resistant
- Can be stored outside
- Traditional methods used for installation
- Can be used with hot-pour and cold-applied sealants
- Clean product
- Inert
- Recyclable
- Reusable
- Made in USA



Insert Nomaflex into the channel.



Pull cutter along Nomaflex edge to score tear-strip;
do not remove tear-strip.



Install Nomaflex with tear-strip at the top.



Pour concrete, let set and then pull tear-strip. Apply sealant per specifications.